

S-fold the bridle across the bottom of the lower staging flap. Don't tuck the S-folds under the side flaps.



Close the bottom flap carefully, keep the bridle folds stacked neatly. Secure the flap with the temporary pins.



Close the top flap and secure it with the reserve handle pins. The reserve static line system must be in place on the pins before the pins are placed through the closing loops.



Check the reserve static line for proper routing, and remove the pull-up cords. Seal the parachute using red safety thread, a lead seal and a seal press.



Check the hook knife. Put the due date and name on a piece of tape as shown. Fill out the data card, your personal log and master log.

